



MODEL
MCK-A



Stainless Steel Straw bottle

Cold drinks only

Instructions

Thank you for purchasing a “TIGER” Stainless Steel Straw bottle.
Please read the instructions completely before use. Keep these instructions for future reference.

Part names



For ages
18 months and up

Make sure that all parts are present before use.



© 2003 TIGER CORPORATION

Safety Precautions

Do not remove the caution s

Important!

Do not put hot beverages in the product.

To prevent burns.



Keep out of reach of children. Do not allow children to play with the product.

To prevent injury.



Be sure to set the lid body and lid cap in proper position.

To prevent leakage of beverages and stains on clothes.

Do not put dry ice or carbonated beverages in the product.


To prevent the lid cap from getting stuck due to a change of the air pressure inside the product. Even if the lid cap can be opened, the beverage may burst out or the lid cap or stopper may be damaged and pop out, causing injury.

Do not store milk, dairy products, or fruit juices in the product.

To prevent corrosion or spoilage. If the product is left for a long time, spoilage or corrosion may create gases that raise the internal air pressure. Then, if the lid body is opened, the beverage may burst out or the lid body may be damaged, causing injury.

Do not exceed the amount of beverage as shown in the figure below.

To prevent leakage or spillage of beverages.



Do not use the product near an open flame, such as that from a gas heater or gas stove.

To prevent skin burns and deformation or discoloration of the product.

Do not heat the product in a microwave oven.

To prevent injury to the skin or failure of the product due to sparks.

Do not press the open button when the product is tilted or near your face.

To prevent spillage of the beverage and staining of your clothes.

on the sticker on the product or the sticker on the bottom.

Do not store soups or beverages containing salt in the product.

To prevent spoilage or corrosion of the beverage or rusting of the product.

Do not put tea leaves or fruit pulp in the product.

To prevent clogging of the straw or leakage of the beverage.

Do not use the product with hot water or hot drinks.

Use with cold drinks only.

Do not put the product in a freezer.

To prevent spillage of the beverage or damage to the product.

Do not knock over or drop the product or expose it to excessive shocks.

To prevent damage to the product, loss of its cold-retention ability, rusting of the product, peeling of the exterior painting, or leakage of the beverage.

Do not use chlorine-based bleaches to wash the product.

This may cause rust or a hole on the product.

Be sure to clean the product immediately specially after sports drink.

Even if you are going out, for example, and don't have time to wash the product thoroughly, be sure to rinse out the inside of it. To prevent the occurrence of mold, rust, or holes on the product.

Do not disassemble or attempt to repair the product by yourself.

To prevent failure and accidents.

Keep the product in an upright position at all times.

To prevent possible leakage of beverages.

Do not leave the product in a bag for a long time.

To prevent rust or odors caused by a change in storage conditions.



Do not remove the protective sheet on the underside of the product.

To prevent loss of its cold-retention ability.

Do not scrape or rub off the patterns or stickers on the surface of the product using a fingernail or hard tool.

To prevent the sticker from being removed.

Do not use the product in a moving vehicle.

To prevent the interior of the vehicle or clothes from becoming stained. Using the product in a moving vehicle is dangerous, as the driver's attention may be distracted.

Do not bite or chew on the spout.

To prevent choking or leakage of the beverage.

How to Use

First!

Before the first use


Cleaning

You may notice an unusual odor coming from the material of the product. In this case, clean the product by following the steps below.

- (1) Check that the gasket is attached.
- (2) Pour hot water into the main body, securely close the stopper, and then close the lid cap correctly.
- (3) Hold the main body and shake it repeatedly to wash the inside of the product. (To prevent burns caused by leaking water, do not shake the product too hard.)
- (4) Discard the hot water, and then wash each part.

1


Turn to remove the stopper.



2

Press the open button and open the lid cap to check that the straw is set correctly.

After the check, close the lid cap.



3


3

To keep your beverage cool longer, first pour a small amount of cold water into the main body and let it sit for one or two minutes. Discard the cold water after precooling.

4

Pour your cold beverage into the main body.


- Do not fill the product above the maximum level shown below.



- Do not insert large cubes of ice. Use small cubes or crushed ice.

Caution


- Be sure to wipe off any spilled beverages.



5


Turn the stopper to securely close it.

- Check that the straw is attached correctly.
- Turn the stopper as far as it will go. After checking that the cap is securely closed, slide up the safety lock.



6


Slide down the safety lock, press the open button, and open the lid cap to drink.



7

After drinking the beverage, keep the product in an upright position and close the lid cap. Then slide up the safety lock.

The safety lock is securely engaged when you hear a clicking sound.



How to Clean

- ◆ Clean after every use.
- ◆ Use mild kitchen detergent.
- ◆ Use a sponge or soft cloth.
- ◆ Be sure to clean the lid and gasket every use.



Main body



Straw unit
(Remove and wash it.)



Stopper



Gasket
(Remove and wash it.)



Protective
cover

- (1) Wash each part using a sponge with diluted detergent water or lukewarm water, and then thoroughly rinse it with water.
- (2) Use a dry cloth to wipe off the moisture on the outer surface of the main body.
- (3) Drain out all the water and dry the inside of the main body.


Caution

- Do not soak the main body and lid body when washing them.
- When washing the product, do not use thinners, vinegar, cleansers, bleaches, chemical agents, metallic scrubbing brushes, or nylon scrubbing brushes. This may affect the cold-retention ability of the product.
- Do not use a dishwasher or dish dryer, and do not wash with boiling water.
- Be sure to attach the gasket and straw correctly before use.
- When the product is not used for a long period of time, thoroughly wash out any stains and then dry it.

Attaching and removing the gasket and straw unit

Attaching and removing the gasket


To remove



Fit the end of a toothpick or another long, thin, soft tool into the fixing groove and pull out the gasket. (Do not use a metal skewer.)

To attach

Fit the gasket correctly into the fixing groove.




Caution

Check the correct orientation of the gasket and fit it into the end of the groove so that the beverage does not leak.

Attaching and removing the straw unit


To remove

- ① Open the lid cap and pull out the straw unit from under the lid body.
- ② Remove the straw from the bottom of the spout.



To attach

- ① Insert the straw from the bottom of the spout and fix it in position.
- ② Insert the spout through the hole from the bottom of the lid body and set the straw unit in position. Then pull out the spout from the top of the lid body and fix the straw unit in position.



MCK-A

Specifications

Capacity		0.28 L / 9.6 oz
Cold retention	6 hours	Less than 11°C/ 52°F

※ Cold retention has been calculated under the condition of adding cold water at 4°C±1°C / 39°F±2°F and leaving it in a room temperature of 20°C±2°C / 68°F±4°F for 6 hours.

※ Capacity is actual volume that water can be stored into the product when the stopper is attached. This is not the “slightly less than full” volume described in “Safety Precautions”.

Replacing and Purchasing Consumable Parts

The stopper is a consumable part. Check once a year for damage/deterioration. If heavily stained or loose, replace them. For replacement parts, contact customer service or the shop where you purchased this product.

Before contact customer service

The utmost measures have been taken to ensure the quality of this product. Should the product be defective, however, contact your dealer and provide the following information.

1. Product name
2. Model number
3. Description of trouble (As detailed as possible)
4. Purchase date

Feel free to send any questions or comments about this product to the shop where you purchased it.

For the purpose of performance improvement, designs, specifications and parts shown in this publication are subject to change without notice.



TIGER CORPORATION

Head Office: 3-1 Hayami-cho, Kadoma City, Osaka 571-8571, Japan
URL : <https://usa.tiger-corporation.com>

TIGER CORPORATION HONGKONG LIMITED

Rm. 1006B, 10/FI., Join-in Hang Sing Centre, 71 - 75 Container Port Road, Kwai Chung, N.T.

Tel: (852) 2418-0912 Fax: (852) 2418-0911

TIGER CORPORATION U.S.A.

1815 W.205th Street, Unit 106, Torrance, CA 90501
Tel: (310) 787-1985 Fax: (310) 787-1986